DuPont[™] Fodel[®] 5989 PHOTOIMAGEABLE THICK-FILM PASTE

Technical Data Sheet

Product Description

DuPont[™] Fodel[®] 5989 photoimageable thickfilm paste gold conductor is an inner and top layer photoimageable thick film composition specially developed to be compatible with:

- Alumina
- DuPont 5704 dielectric
- Low-temperature cofire ceramic (LTCC), post -fired (LTCC-external use only)

Product Benefits

Fodel® 5989 gold conductor is compatible with Fodel® QM44F dielectric and conventional DuPont 5704 dielectric compositions. Fodel® 5989 conductor offers the following benefits:

- Precise conductor line edge acuity
- No screen printing pattern distortion
- Excellent wire bond interconnections
- Excellent line and space resolution
- Extremely high conductor and via density, when used with Fodel® QM44F dielectric

Processing

Storage

Fodel® 5989 gold conductor composition should be thoroughly mixed prior to use. Jar-rolling is not recommended. Paste must be stored in opaque containers and should be opened and handled in yellow safe light areas (Fodel® Safe Lighting).

Substrates

Properties were measured on 96% Alumina substrates. Substrates of other compositions and from various manufacturers may result in performance property variations.

Typical Fired Properties

Test	Properties
Line/Space Resolution (µm) (7-8µm fired thick)	40/50
Resistivity (mΩ/sq) [7-8µm fired thickness)	< 6
Wire Bond Performance [°] 1 mil Au thermosonic, ball (g) 1 mil Al ultrasonic, wedge (g) Aged 1 mil Al (g) (1.25 hours @ 315°C)	10 12 6 - 7 No lifts
Fired Thickness (µm)	7-8

Composition Properties

Viscosity (Pa.S) (Brookfield HBT utility cup &spindle#14, 10 rpm, 25°C)	40-100
Print Speed (cm/sec)	5-12 cm/sec
Coverage² (cm²/g)	75-85
Thinner	DuPont 9450

 8 Typical wire bond properties are based on laboratory test on DuPont QM44F and 96% Alumina substrates, using recommended processes and procedures 8 Calculated at dry thickness of 17 μm

This table show anticipated typical physical properties for Fodel® 5989 based on specific controlled experiments in our labs and are not intended to represent the product specifications, details of which are available upon request.

Printing

Print a single conductor layer with a 280-mesh (30μ m wire) or 325 mesh (28μ m wire) stainless steel screen. The thickness of the final fired conductor will be about 50% of the dried conductor thickness. The print speed is 5-12 cm/sec, using a single wet pass.

Drying

Allow the wet print to level for 5-10 minutes at room temperature. Dry for 15-25 minutes at 80°C. Higher drying temperatures or longer drying times will deactivate the photosensitive system.

Exposure

Expose the conductor layer (15-18 μ m) dried thickness) with the appropriate photo tool and a Hg or Hg/Xe ultraviolet light source (365 nm.). The recommended exposure energy range is 450-1200 mJ/cm². This corresponds to a 30-75 second exposure on a high intensity (1kW) UV light source.

Development

The development process is conducted in a conveyorized, spray development unit filled with 0.8-1.0% Na₂CO₃ at 85°F (30°C). Total development time will depend upon equipment design, spray pressure, and Fodel® conductor thickness. The total cleaning time (TTC) for a dried, unexposed sample of the conductor should be determined. The exposed conductor samples should then be developed for 1.3-1.5 x the TTC. The samples should be rinsed with water immediately after development, normally in the same piece of equipment. The excess water is then removed by blow-drying with ambient or warm air.

Firing

DuPont[™] Fodel® 5989 photoimageable thickfilm paste is normally fired in a belt furnace. A 60-minutes firing cycle with a peak temperature of 850°C for 10 minutes is recommended (Figure 1).




Figure 1. Firing Profile (Typical 850°C 60 minute Profile)



Related Data Sheets

Fodel(®Safe Lighting Fodel®Q170P silver/platinum conductor Fodel®6778 silver conductor Fodel® QM44F dielectric

Safety and Handling

For Safety and Handling information pertaining to this product, read the Material Safety Data Sheet (MSDS).

Copyright © 2009 DuPont. All rights reserved. The DuPont Oval, DuPont[™], The miracles of science[™], Green Tape[™] and all products or words denoted with ® or [™] are registered trademarks or trademarks of E. I. du Pont de Nemours and Company or its affiliates ("DuPont"). NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT.

Caution: Do not use in medical applications involving implantation in the human body or contact with internal body fluids or tissue unless the product is provided by DuPont under a formal written contract consistent with the DuPont Policy Regarding Medical Applications of DuPont Materials H -50103-2 ("Medical Applications Policy") and which expressly acknowledges the contemplated use. For additional information, please request a copy of DuPont Medical Caution Statement H-50102-2 and the DuPont Medical Applications Policy.

The information provided herein is offered for the product user's consideration and examination. While the information is based on data believed to be reliable, DuPont makes no warranties, expressed or implied as to the data's accuracy or reliability and assumes no liability arising out of its use. The data shown are the result of DuPont laboratory experiments and are intended to illustrate potential product performance within a given experimental design under specific, controlled laboratory conditions. While the data provided herein falls within anticipated normal range of product properties based on such experiments, it should not be used to establish specification limits or used alone as the basis of design. It is the product user's responsibility to satisfy itself that the product is suitable for the user's intended use. Because DuPont neither controls nor can anticipate the many different end-uses and end-use and processing conditions under which this information and/or the product described herein may be used, DuPont does not guarantee the usefulness of the information or the suitability of its products in any given application. Users should conduct their own tests to determine the appropriateness of the products for the product is a process.

The product user must decide what measures are necessary to safely use the product, either alone or in combination with other products, also taking into consideration the conditions of its facilities, processes, operations, and its environmental, health and safety compliance obligations under any applicable laws.

This information may be subject to revision as new knowledge and experience become available. This publication is not to be taken as a license to operate under, or recommendation to infringe any patent.

UPOND The miracles of science[™] For more information on DuPont™ Fodel® 5989 photoimageable thickfilm paste or other DuPont Microcircuit Materials products, please contact

your local representative:

Americas

DuPont Microcircuit Materials

14 T.W. Alexander Drive

Research Triangle Park, NC 27709

Tel.: 800-284-3382

Europe

Du Pont (U.K.) Limited

Coldharbour Lane

Bristol BS16 1QD

U.K.

Tel.: 44-117-931-3191

Asia

DuPont Kabushiki Kaisha

MCM Technical Lab

DuPont Electronics Center

KSP R&D B213

2-1, Sakado 3-chom, Takatsu-ku,

Kawasaki-shi, Kanagawa, 213-0012

Japan

Tel +81 44 820 7575

DuPont Taiwan Ltd

45, Hsing-Pont Road, Taoyuan, Taiwan 330 Tel.: 886-3-377-3616

DuPont China Holding Co. Ltd

Bldg 11, 399 Keyuan Rd., Zhangji Hi-Tech Park, Pudong New District, Shanghai 201203, China Tel.: 86-21-6386-6366 ext.2202

DuPont Korea Inc.

3~5th Floor, Asia tower #726, Yeoksam-dong, Gangnam-gu Seoul 135-719, Korea Tel.: 82-10-6385-5399

E. I. DuPont India Private Limited 7th Floor, Tower C, DLF Cyber Greens, Sector-25A, DLF City, Phase-III, Gurgaon 122 002 Haryana, India Tel.: 91-124-4091818

Du Pont Company (Singapore) Pte Ltd 1 HarbourFront Place, #11-01 HarbourFrong Tower One, Singapore 098633 Tel.: 65-6586-3022

http://mcm.dupont.com